
Daewoo 1

Red Cable: +12V Blue Cable: GND Green Cable: CODE Black Cable: CAN-H

White Cable: CAN-L

After adjusting,
LED-- It lights up constantly,



DAEWOO 1

In Universal IMMO Emulator, solder jumpers J1, J2 and J3


USE

ECUs with white - red sockets and ECUs with blue sockets


ECU with white - red socket



This emulator requires modification of Motorola HC11F1 processor located in ECU.



In address 10, write value 73 00 73 00 twice



Once you modified Motorola, connect emulator to the ECU as pictured.

Before connecting the emulator, it must be precisely insulated with insulation tape and the

original immobiliser must be disconnected!!!


In case of problems with starting the car, disconnect power supply (+12V) in ECU and connect

+12V ACC in place of power supply.



ECU with blue socket

This emulator requires modification of Motorola HC11F1 processor located in ECU



In address 10, write value **73 00 73 00** twice Once you modified Motorola, connect emulator to the ECU as pictured.

+5V VCC	leg 11 of DELCO 9621 unit
GND	GND of resonator (quartz)
Code	leg 1 of DELCO 9621 unit

Disconnect immo or cut off pin B7 from ECU

Before connecting the emulator, it must be precisely insulated with insulation tape and the original immobiliser must be disconnected!!!

In case of problems with starting the car, **disconnect power supply (+12V) in ECU**and connect
+12V ACC in place of power supply.

Warning!!!
Due to possible construction changes of cars, check signals with multimeter in the ECU plug.