# **Opel immo with HC05**


# **Emulator**

Red Cable: +12V **Blue Cable: GND** Green Cable: CODE Black Cable: CAN-H White Cable: CAN-L

After adjusting,

LED-- Power

LED-- It lights up constantly, and blink every two seconds



In Universal Emulator solder jumpers J1 J2, J3 and J4

## USE


1.2 and 1.4 gasoline 2-socket (black) ECU with Motorola HC11E20 processor

2.0 2.2 and 2.5 gasoline with 24C02 eeprom memory


### 1.2 and 1.4 gasoline 2-socket (black) ECU with Motorola HC11E20 processor




### Find Motorola HC11E20 processor



#### In address **1FD** write **0F** value





Disconnect immo and connect pin 6 with 7 in the wiring of immo plug to eliminate troubles with speed signal




2.0 2.2 and 2.5 gasoline with 24C02 eeprom memory





Disconnect immo and connect pin 6 with 7 in the wiring of immo plug to eliminate troubles with speed signal



Disconnect immo and connect pin 6 with 7 in the wiring of immo plug to eliminate troubles with speed signal

## Warning!!!

Due to possible construction changes of cars, check signals with multimeter in the ECU plug.