
ZHENGZHOU NISSAN

Read security code

Shuaike 1.6

Immobiliser

Shuaike 1.5

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

Erase key 2

Erase key 3

Erase key 4

Erase key 5

Replace immobiliser ECU

Replace engine ECU

Program immobiliser VIN

Program engine VIN

Reset engine ECU

Reset immobiliser

Shuaike 1.6

Shuaike 2.0

Ruiqi

ECU identification

Fault codes

Erase DTC

Live data

Set security code

Set security code

Input security code

Program function

Program new system

Program keys

Erase keys

Erase all keys

Erase key 1

- Erase key 2
- Erase key 3
- Erase key 4
- Erase key 5
- Replace immobiliser ECU
- Replace engine ECU
- Program immobiliser VIN
- Program engine VIN
- Reset engine ECU
- Reset immobiliser
- Oting diesel
 - ECU identification
 - Fault codes
 - Erase DTC
 - Live data
 - Set security code
 - Set security code
 - Input security code
 - Program function
 - Program new system
 - Program keys
 - Erase keys
 - Erase all keys
 - Erase key 1
 - Erase key 2
 - Erase key 3
 - Erase key 4
 - Erase key 5
 - Replace immobiliser ECU
 - Replace engine ECU
 - Program immobiliser VIN
 - Program engine VIN
 - Reset engine ECU
 - Reset immobiliser
- Other type
 - ECU identification
 - Fault codes
 - Erase DTC
 - Live data
 - Set security code
 - Set security code
 - Input security code
 - Program function
 - Program new system

Program keys
Erase keys
 Erase all keys
 Erase key 1
 Erase key 2
 Erase key 3
 Erase key 4
 Erase key 5
Replace immobiliser ECU
Replace engine ECU
Program immobiliser VIN
Program engine VIN
Reset engine ECU
Reset immobiliser