


# Description of basic SuperVAG functions


## Choose from models and Autodetection

Display all models for manual selection and choose from list of all models or use autodetection button (image #1).



## How to choose Control Unit

On this screen (image #2) you can see available Control Units on selected vehicle. You can choose from often used units (engine, dashboard and so on or click on List of all Units and choose from complete list (images #3).






image #3 – List of all Units

## Functions and Comfort Functions

Functions include adaptation, basic settings and similar functions (image #4). Smart functions are complex solutions with only a few clicks.





image #4 – Functions and Comfort Functions


If there is that many Comfort functions that they will not fit into one line, they are moved under one small arrow button. Click on it and menu with all options will appear (image #5).



*image #5 – Comfort Functions menu*

### Special communication mode

Special communication mode is used for trouble code detection and erase of trouble codes on entire vehicle (image #6 and #7).



*image #6 – Special communication mode*

