Kia Sportage 2.0 TD IMMO Emulator

Red Cable: +12V Green Cable: CODE Black Cable: CAN-H


Blue Cable: GND

White Cable: CAN-L

After adjusting, LED-- It lights up constantly, and blink every two seconds

Kia Sportage 2.0 TD IMMO Emulator

In Universal Emulator, solder jumpers J1 and J4



USE

Kia Sportage 2.0 TD

ZEXEL ECU immo with remote control






ECU is located under the floor mat at the front of the passenger-side footwell.



Connecting emulator to ECU







Warning!!!

Due to possible construction changes of cars, check signals with multimeter in the ECU plug.