
SAAB

Auto reset

9-4X

2012

9-5

2011-2012

9-7X

2008-2009

2005-2007

Type 1

Type 2

Other

Manual reset

9-3

2005

9-3 First Generation

1998-2002

9-3 Second Generation

2003-2006

2007-2013

9-5

2005

9-7X

2005-2009

900

1994-1998

Other

1999-2002